

HITACHI **SERVICE MANUAL**

TY

No.452 E

TRK-W22


H, HC, E, E(BS), W, AU

TN-33ZVC-681 Chassis

TN-33ZVC-682 Chassis

CONTENTS

SPECIFICATIONS	2
DISASSEMBLY	3
ADJUSTMENT	4-7
INSPECTION OF MECHANISM	7, 8
LUBRICATION	8
DIAL CORD STRINGING	8
CIRCUIT DIAGRAM	9-12
PRINTED WIRING BOARD	13, 14
EXPLODED VIEW	15, 16
REPLACEMENT PARTS LIST ..	17-19



KEY TO ILLUSTRATIONS

- | | |
|--------------------------|------------------------------------|
| ① FUNCTION SELECTOR | ⑩ ROD ANTENNA |
| ② TONE CONTROL | ⑪ BAND SELECTOR |
| ③ VOLUME CONTROL | ⑫ TUNING CONTROL |
| TAPE 1 | ⑬ FINE TUNING CONTROL (W, AU only) |
| ④ PAUSE BUTTON | ⑭ 2 cm TWEETER |
| ⑤ STOP/EJECT BUTTON | ⑮ INNER MICROPHONE (MONAURAL) |
| ⑥ FAST FORWARD BUTTON | ⑯ 10 cm SPEAKER |
| ⑦ REWIND BUTTON | ⑰ TAPE 1 CASSETTE HOLDER |
| ⑧ PLAYBACK BUTTON | ⑱ TAPE 2 CASSETTE HOLDER |
| ⑨ CONTINUOUS PLAY BUTTON | ⑲ TAPE COUNTER |
| TAPE 2 | ⑳ COUNTER RESET BUTTON |
| ⑩ PAUSE BUTTON | ㉑ FM STEREO INDICATOR |
| ⑪ STOP/EJECT BUTTON | ㉒ TAPE 1 INDICATOR |
| ⑫ FAST FORWARD BUTTON | ㉓ TAPE 2 INDICATOR |
| ⑬ REWIND BUTTON | |
| ⑭ PLAYBACK BUTTON | |
| ⑮ RECORD BUTTON | |

SPECIFICATIONS AND PARTS ARE SUBJECT TO CHANGE FOR IMPROVEMENT.

RADIO/DOUBLE CASSETTE TAPE RECORDER

May 1985

TOYOKAWA WORKS

SAFETY PRECAUTION

The following precautions should be observed when servicing.

1. Since many parts in the unit have special safety-related characteristics, always use genuine Hitachi's replacement parts. Especially critical parts in the power circuit block should not be replaced with other makes. Critical parts are marked with Δ in the circuit diagram and printed wiring board.
2. Before returning a repaired unit to the customer, the service technician must thoroughly test the unit to ascertain that it is completely safe to operate without danger of electrical shock.

SPECIFICATIONS

General Section

Semiconductors

ICs : 4
Transistors : 10 [For E]
9 [For E (BS), W, (AU)]
8 [For H, HC]

Diodes : 16 [For W]
15 [Except W]

LEDs : 3

Power supply

AC : 220 V, 50 Hz [For E]
AC : 240 V, 50 Hz [For E (BS), AU]
AC : 110 - 127 V/200 - 220 V
230 - 250 V, 50/60 Hz [For W]
AC : 120 V 60 Hz [For H, HC]
DC : 9 V ("D" CELL or IEC R20 \times 6
or equivalent)

Power Consumption

16 W

Power Output

9 W P.M.P. (AC operation)
6 W M.P.O. (AC operation)
2 W/CH (T.H.D. 10 % DC)

Speakers

Woofer : 10 cm, 4 ohms \times 2
Tweeter : 2 cm, 300 ohms \times 2

Dimensions

570(W) \times 208(H) \times 132(D) mm

Weight

4.3 kg (with batteries)

Radio Section

Circuit System

FM/SW/MW/LW 4-band
[For E, E (BS)]
FM/SW2/SW1/MW 4-band
[For W, AU]
FM/AM 2-band [For H, HC]

Tuning Range

Superheterodyne
FM : 87.5 to 108 MHz
SW : 6 to 18 MHz
MW : 530 to 1,605 kHz
LW : 150 to 285 kHz
FM : 88 to 108 MHz
SW2 : 7 to 22 MHz
SW1 : 2.3 to 7 MHz
MW : 530 to 1,605 kHz
FM : 88 to 108 MHz
AM : 530 to 1,605 kHz

Intermediate Frequency

FM : 10.7 MHz
AM : 465 kHz [For E, E (BS)]
AM : 455 kHz [For W, AU, H, HC]

Sensitivity

FM : 12 dB (pra.), 3 dB (max.)
SW : 30 dB (pra.), 20 dB (max.)
MW : 48 dB (pra.), 40 dB (max.)
LW : 55 dB (pra.), 48 dB (max.)

FM : 12 dB (pra.), 3 dB (max.)
SW2 : 30 dB (pra.), 27 dB (max.)
SW1 : 45 dB (pra.), 38 dB (max.)
MW : 48 dB (pra.), 40 dB (max.)

FM : 12 dB (pra.), 3 dB (max.)
AM : 48 dB (pra.), 40 dB (max.)

Antennas (Aerials)

FM/SW : Rod antenna
MW/LW : Built-in ferrite core
antenna

FM/SW2 : Rod antenna
SW1/MW : Built-in ferrite core
antenna

FM : Rod antenna
AM : Built-in ferrite core
antenna

Tape Recorder Section

Tape

Cassette tape (C-30, 60, 90)

Track System

4 track 2 channel stereo

Recording System

AC bias, 55 kHz

Erasing System

DC erase

Frequency Response

Normal : 60 to 10,000 Hz

Signal to Noise Ratio

40 dB

Wow and Flutter

0.25 % (WRMS)

Cross Talk

Between tracks : 65 dB
Between channels : 40 dB

Input Sensitivity and Impedance

Mic : 0.6 mV, 1.2 kohms
Line-in : 500 mV, 330 kohms

Output Load Impedance

Headphone : 8 ohms-100 ohms

Distortion

3 %

Erasing Ratio

60 dB

Fast Forwarding or Rewinding time

110 sec (using C-60)

Motor

DC motor

Heads

Permalloy

DISASSEMBLY

1. Cassette lid Removal (Fig. 1)

Insert a screw driver (→) in the direction of arrow to remove the claw.




Fig. 1

2. Rear Case Removal (Fig. 2, 3)

- (1) Remove the battery lid.
- (2) The rear case can be removed by removing 8 screws (A). Remove pin connectors P101 of the Tuner P.W.B. and PL601 of the Power P.W.B. at that time.




Fig. 2

3. Tuner P.W.B. Removal (Fig. 3)

Remove the fixing screw (B) and pull the Tuner P.W.B. toward you out of 2 guide pins.




Fig. 3

4. Main P.W.B. Removal (Fig. 3)

- (1) Pull out the TONE, VOLUME knobs.
- (2) Remove 2 fixing screws (C) and the Main P.W.B. is removed when the terminals (LINE IN, EXT MIC, PHONES) and switches (INN MIC, SP, FM MODE, RIF) are pulled out of the front case.

5. Cassette chassis (TAPE 1 and TAPE 2) Removal (Fig. 3)

The cassette chassis (TAPE 1 and TAPE 2) are removed while they are assembled together by removing 4 screws (D).

6. Speaker Removal (Fig. 4)

Remove 4 fixing screws (E) after the Tuner P.W.B. and Main P.W.B. are removed.




Fig. 4

7. Power P.W.B. Removal (Fig. 5)

Remove 2 screws (F) and pull out the Power P.W.B. toward the front.




Fig. 5

ADJUSTMENT

1. Radio Section

FM Section

* () For W. Germany

Step	Adjustment Item	Measuring Instrument and Connection			Genescope or Signal Generator Frequency	Dial Pointer Position	Adjust	Reading
		Measuring Instrument	Input Terminal	Output Terminal				
1	(1) FM IF	Turn T202 fully counterclockwise.						
	(2) S-Curve	• Genescope (10.7 MHz)	TP102	TP201	10.7 MHz	Highest	T101 T202	Note 1 Note 2
2	(1) FM OSC (Covering)	• FM signal generator (400 Hz, 30 % Dev.) • Oscilloscope • VTVM	TP101 (thru FM dummy antenna) (Note 3)	TP201	87 MHz * (87.5 MHz)	Lowest	L102	Max.
	(2)				109 MHz * (108 MHz)	Highest	CT102	
	(3)				Repeat steps (1) and (2)			
3	(1) FM ANT. (Tracking)	• VTVM			90 MHz	90 MHz	L101	Max.
	(2)				106 MHz	106 MHz	CT101	
	(3)				Repeat steps (1) and (2)			
4	(1) FM MPX. (Multiplex)	• Frequency counter	Connect a 10 μ F 25 V electrolytic capacitor between the No.12 pin of IC301 and the ground	TP301	—	—	RT301	19 kHz \pm 20 Hz (Note 4)

AM Section



Step	Adjustment Item	Measuring Instrument and Connection			Genescope or Signal Generator Frequency	Dial Pointer Position	Adjust	Reading
		Measuring Instrument	Input Terminal	Output Terminal				
1	(1) AM IF	• Genescope (465 kHz)	Ferrite-core antenna (Note 5)	TP201	465 kHz	Highest	T201 T203	Note 6
	(2)				Repeat step (1)			
2	(1) LW OSC. (Covering)	• AM signal generator (400 Hz, 30 % Dev.) • VTVM	Ferrite-core antenna (Note 5)	TP201	145 kHz	Lowest	L156	Max.
	(2)				290 kHz	Highest	CT156	
	(3)				Repeat steps (1) and (2)			
3	(1) LW ANT. (Tracking)	• VTVM			160 kHz	160 kHz	L153	Max.
	(2)				270 kHz	270 kHz	CT153	
	(3)				Repeat steps (1) and (2)			
4	(1) MW OSC. (Covering)	• AM signal generator (400 Hz, 30 % Dev.) • VTVM	Ferrite-core antenna (Note 5)	TP201	515 kHz	Lowest	L155	Max.
	(2)				1650 kHz	Highest	CT155	
	(3)				Repeat steps (1) and (2)			
5	(1) MW ANT. (Tracking)	• VTVM			600 kHz	600 kHz	L152	Max.
	(2)				1400 kHz	1400 kHz	CT152	
	(3)				Repeat steps (1) and (2)			
6	(1) SW OSC. (Covering)	• AM signal generator (400 Hz, 30 % Dev.) • VTVM	TP101 (thru SW. dummy antenna) (Note 7)	TP201	5.8 MHz	Lowest	L154	Max.
	(2)				18.5 MHz	Highest	CT154	
	(3)				Repeat steps (1) and (2)			
7	(1) SW ANT. (Tracking)	• VTVM			6.5 MHz	6.5 MHz	L151	Max.
	(2)				16 MHz	16 MHz	CT151	
	(3)				Repeat steps (1) and (2)			

Step			Adjustment Item	Measuring Instrument and Connection			Genescope or Signal Generator Frequency	Dial Pointer Position	Adjust	Reading
				Measuring Instrument	Input Terminal	Output Terminal				
For W/AU	8	(1)	AM IF	● Genescope (455 kHz)	Ferrite-core antenna (Note 5)	TP201	455 kHz	Highest	T201 T203	Note 6
		(2)					Repeat step (1)			
	9	(1)	MW OSC. (Covering)	● AM signal generator (400 Hz, 30 % Dev.) ● VTVM	Ferrite-core antenna (Note 5)	TP201	515 kHz	Lowest	L156	Max.
		(2)					1650 kHz	Highest	CT156	
		(3)					Repeat steps (1) and (2)			
	10	(1)	MW ANT. (Tracking)				600 kHz	600 kHz	L153	Max.
		(2)					1400 kHz	1400 kHz	CT153	
		(3)					Repeat steps (1) and (2)			
	11	(1)	SW 1 OSC. (Covering)	● AM signal generator (400 Hz, 30 % Dev.) ● VTVM	TP101 (thru SW. dummy antenna) (Note 7)	TP201	2.2 MHz	Lowest	L155	Max.
		(2)					7.3 MHz	Highest	CT155	
		(3)					Repeat steps (1) and (2)			
	12	(1)	SW 1 ANT. (Tracking)				2.7 MHz	2.7 MHz	L152	Max.
		(2)					6.3 MHz	6.3 MHz	CT152	
		(3)					Repeat steps (1) and (2)			
	13	(1)	SW 2 OSC. (Covering)	● AM signal generator (400 Hz, 30 % Dev.) ● VTVM	TP101 (thru SW. dummy antenna) (Note 7)	TP201	6.7 MHz	Lowest	L154	Max.
		(2)					23 MHz	Highest	CT154	
		(3)					Repeat steps (1) and (2)			
	14	(1)	SW 2 ANT. (Tracking)				8 MHz	8 MHz	L151	Max.
		(2)					20 MHz	20 MHz	CT151	
		(3)					Repeat steps (1) and (2)			
For H/HC	15	(1)	AM IF	● Genescope (455 kHz)	Ferrite-core antenna (Note 5)	TP201	455 kHz	Highest	T201 T203	Note 6
		(2)					Repeat step (1)			
	16	(1)	MW OSC. (Covering)	● AM signal generator (400 Hz, 30 % Dev.) ● VTVM	Ferrite-core antenna (Note 5)	TP201	515 kHz	Lowest	L155	Max.
		(2)					1650 kHz	Highest	CT152	
		(3)					Repeat steps (1) and (2)			
	17	(1)	MW ANT. (Tracking)				600 kHz	600 kHz	L152	Max.
		(2)					1400 kHz	1400 kHz	CT151	
		(3)					Repeat steps (1) and (2)			

Note :

1. Feed in a weak signal to TP102 from the genescope. Adjust T101 for maximum gain and the waveform indicated in Fig. 6. If the center of the waveform cannot be lined up on the marker, adjust the right/left balance.
2. Use the T202 core to form the S-curve shown in Fig. 7. Adjust the symmetry of A and B about point C for linearity.

Adjust the genescope output so that there is a little noise riding on the leading edge.


Fig. 6

Fig. 7

3. FM dummy antenna is shown in Fig. 8.




Fig. 8

6. Feed in a weak signal from the genescope. Adjust T201, T203 for maximum gain and the waveform of Fig. 9.




Fig. 9

4. Connect the frequency counter to TP301 and connect a 100 kΩ resistor series with the frequency counter.

5. Connect the output of AM signal generator to the loop antenna, and put it near to the ferrite antenna.

7. SW. dummy antenna is shown in Fig. 10




Fig. 10

2. Tape Recorder Section

Perform the following adjustments in the sequence stated after cleaning the head, pressure roller, and capstan with a head cleaning stick moistened in alcohol.

Step	Adjustment Item	Measuring Instrument and Connection			Check Tape	Mode	Adjusted Position	Adjusted Value	Remarks
		Measuring Instrument	Input Terminal	Output Terminal					
1	Tape speed	● Frequency counter	—	Speaker terminal	Tape speed adjustment tape (3 kHz)	Playback	Semivariable resistor in the motor P.W.B. (Fig. 11)	3 kHz ± 20 Hz	Note 1
2	Head azimuth	● VTVM	—	Speaker terminal	Head azimuth adjustment tape (10 kHz)	Playback	Azimuth adjusting screw	Output max.	Note 2

Note :

1. Adjust within 30 sec. after heat-running for more than 20 minutes.
2. When the maximum values of both channels are different, adjust to the maximum value of the L channel. In this case, the difference between the maximum values of both channels should be within 2 dB.





Fig. 11

ADJUSTMENT PARTS LOCATION

• TUNER SECTION



INSPECTION OF MECHANISM

Item	Checking item		Reference value	Remarks
1	Pressure of pressure roller		300 – 500 g	Note
2	Take-up torque		35 – 65 g.cm	
3	Fast forward/Rewind torque		60 – 140 g.cm	TAPE 2
			60 – 140 g.cm	TAPE 1
4	Auto-Stop sensor operation force		40 – 75 g	
5	Brake torque		15 g.cm or more	Measured in stop mode
6	Back tension torque	Take-up	2 – 6.5 g.cm	TAPE 2
			1 – 6 g.cm	TAPE 1
		Supply	2 – 6 g.cm	
7	Flywheel thrust gap		0.05 – 0.5 mm	
8	Button operation force	Play button	1.7 kg or less	
		FF button	1.0 kg or less	
		Rewind button	1.0 kg or less	
		Eject button	1.0 kg or less	
		Record button	1.0 kg or less	
		Pause button	1.5 kg or less	

Note :

Set this unit in the playback mode and press the pressure roller in the direction of the arrow using a fan type tension gauge, and measure the pressure when the pressure roller is released from the capstan.




Fig. 12

LUBRICATION

Lubricate one or two drops of oil to rotating point or lubricate grease to sliding point.

Lubricate the respective parts listed once every 1000 hours or once a year under normal conditions of use.

Avoid oiling them excessively, or rotation may become irregular because of oil splashes.

Lubrication point		Oil or Grase
Rotary section	Metal and metal	Pan motor oil (10 W-40)
	Mold and metal	Sonic slider oil (# 1600)
Sliding section	Metal and metal	Hitasol (MO-138)
	Mold and mold Mold and metal	White grease (FL-LUBE-A)
Spring resonance prevention		Floil (GB-TS-1)

DIAL CORD STRINGING

Stringing method

- String the dial cord to each rollers according to the order from ① to ⑧ after turned the pulley to the end of clockwise direction.





Fig. 13

CIRCUIT DIAGRAM

CAUTION

Use the electrolytic capacitors with explosion-proof valve when the diameter of them is more than 10mm ϕ .

* : Axial lead cylindrical ceramic capacitor



CIRCUIT DIAGRAM


[For H, HC]

CAUTION

Use the electrolytic capacitors with explosion-proof valve when the diameter of them is more than 10mmφ.

* : Axial lead cylindrical ceramic capacitor

TUNER P.W.B.




CIRCUIT DIAGRAM

[For E, E (BS)]

CAUTION
Use the electrolytic capacitors with explosion-proof valve when the diameter of them is more than 10mmφ.

* : Axial lead cylindrical ceramic capacitor

TUNER P.W.B.



CIRCUIT DIAGRAM


[For W, AU]

CAUTION

Use the electrolytic capacitors with explosion-proof valve when the diameter of them is more than 10mm ϕ .


* : Axial lead cylindrical ceramic capacitor

TUNER P.W.B.




[For H, HC]

* : Axial lead cylindrical ceramic capacitor



※ : Axial lead cylindrical ceramic capacitor



IC201																
	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
FM-ST	0V	0V	2.1V	2.3V	0.8V	0.8V	—	0V	1.4V	5.0V	5.0V	1.4V	1.4V	1.4V	1.4V	5.0V
AM	1.5V	1.5V	2.3V	2.3V	0.9V	0.9V	—	0V	1.3V	5.0V	5.0V	1.4V	1.4V	1.4V	1.4V	5.0V

IC301																
	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
FM-ST	5.4V	1.5V	1.8V	1.2V	1.2V	3.9V	0V	0.2V	0V	1.5V	1.5V	1.1V	1.5V	1.5V	1.5V	1.9V
AM	5.4V	1.5V	1.8V	1.2V	1.2V	3.9V	0V	0.2V	2.1V	1.5V	1.5V	2.2V	1.5V	1.5V	1.5V	0.2V

IC401																
	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
PLAY	0V	0.5V	2.0V	4.7V	0V	2.0V	0.5V	0V	0.5V	0V	0V	0V	4.4V	0V	0V	0.5V
REC	0V	0.5V	2.0V	4.7V	0V	2.0V	0.5V	0V	0.5V	0V	0V	0V	4.4V	0V	0V	0.5V

IC501												
	1	2	3	4	5	6	7	8	9	10	11	12
	7.2V	4.3V	8.3V	8.2V	0.6V	0V	0V	0.6V	0V	4.2V	7.2V	9.0V

Q101		
	FM-ST	AM
E	0.6V	4.5V
C	5.0V	5.0V
B	1.3V	4.8V


Q102		
	FM-ST	AM
E	0.65V	4.5V
C	5.0V	5.0V
B	1.3V	4.8V

Q405		
	PLAY	REC
E	5.4V	5.4V
C	9.0V	9.0V
B	6.0V	6.0V


Q403		
	PLAY	REC
E	0V	0.1V
C	0V	3.8V
B	0V	0.75V

Q401LR, Q402LR		
	PLAY	REC
E	0V	0V
C	1.5V	1.5V
B	0.65V	0.65V

※ : Axial lead cylindrical ceramic capacitor



※ : Axial lead cylindrical ceramic capacitor



Q404	
PLAY	REC
E 0V 0V	
C 0V 0V	
B 0V 0V	

Q403	
PLAY	REC
E 0V 0.1V	
C 0V 3.8V	
B 0V 0.75V	

Q401LR, Q402LR	
PLAY	REC
E 0V 0V	
C 1.5V 1.5V	
B 0.65V 0.65V	

Q151	
FM	AM
E 0.15V 0.15V	
C 5.0V 5.0V	
B 0.8V 0.8V	

Q101	
FM	AM
E 0.6V 4.5V	
C 5.0V 5.0V	
B 1.3V 4.8V	

Q102	
FM	AM
E 0.65V 4.5V	
C 5.0V 5.0V	
B 1.3V 4.8V	

IC501											
1	2	3	4	5	6	7	8	9	10	11	12
7.2V	4.3V	8.3V	8.2V	0.6V	0V	0V	0.6V	0V	4.2V	7.2V	9.0V

IC401															
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
PLAY	0V	0.5V	2.0V	4.7V	0V	2.0V	0.5V	0V	0.5V	0V	0V	0V	4.4V	0V	0V
REC	0V	0.5V	2.0V	4.7V	0V	2.0V	0.5V	0V	0.5V	0V	0V	0V	4.4V	0V	0V

IC201															
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
FM	0V	0V	2.1V	2.3V	0.8V	0.8V	—	0V	1.4V	5.0V	5.0V	1.4V	1.4V	1.4V	5.0V
AM	1.5V	1.5V	2.3V	2.3V	0.9V	0.9V	—	0V	1.3V	5.0V	5.0V	1.4V	1.4V	1.4V	5.0V


IC301															
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
FM	5.4V	1.5V	1.8V	1.2V	1.2V	3.9V	0V	0.2V	0V	1.5V	1.5V	1.1V	1.5V	1.5V	1.9V
AM	5.4V	1.5V	1.8V	1.2V	1.2V	3.9V	0V	0.2V	2.1V	1.5V	1.5V	2.2V	1.5V	1.5V	0.2V

Q405	
PLAY	REC
E 5.4V 5.4V	
C 9.0V 9.0V	
B 6.0V 6.0V	

★ No.	E	E(BS)	W	AU	★ No.	E	E(BS)	W	AU
C121	Use	←	—	—	R152	Use	←	—	—
C122	Use	←	←	—	R154	Use	←	—	—
C123	Use	←	—	—	R156	—	—	Use	←
C151	Use	—	—	—	Q151	Use	—	—	—
C152	Use	—	—	—	Jumper 1	Use	—	—	—
C153	Use	←	—	—	Jumper 2	Use	—	—	—
C175	Use	←	—	—	Jumper 3	Use	←	—	—
C176	Use	←	—	—	Jumper 4	—	Use	←	←
R151	Use	—	—	—					


POWER P.W.B.

(for E, E(BS), AU)




POWER P.W.B.

(for W)




EXPLODED VIEW (Cabinet)



EXPLODED VIEW

TN-33ZVC-681/682 [TAPE 2 (R/P)/TAPE 1 (PLAY ONLY)]



REPLACEMENT PARTS LIST

SYMBOL No.	PART No.	DESCRIPTION	SYMBOL No.	PART No.	DESCRIPTION	SYMBOL No.	PART No.	DESCRIPTION
for FRONT CASE ASSEMBLY			for REAR CASE ASSEMBLY					
1	4027421	Front case ass'y [for H, HC]	22	4027451	Rear case ass'y [for H]	38	4582514	2 ϕ × 8 DT screw
	4027422	Front case ass'y [for E, E (BS)]		4027452	Rear case ass'y [for HC]	39	8815113	2.6 ϕ Lock washer
	4027423	Front case ass'y [for W]		4027453	Rear case ass'y [for E]	40	8721406	3 ϕ × 6 Flat head screw
	4027424	Front case ass'y [for AU]		4027454	Rear case ass'y [for E (BS)]	41	0741304	2.6 ϕ × 4 Bind screw
2	4591983	Tuning shaft		4027455	Rear case ass'y [for W]	42	4578282	2.6 ϕ × 5 DT screw (×4)
		[for H, HC, E, E (BS)]		4027456	Rear case ass'y [for W (UN)]	for FINAL ASSEMBLY		
	4591984	Tuning shaft [for W]		4027457	Rear case ass'y [for AU]	43	2667922	Siemens plug [for W]
3	4418013	E ring	23	3973523	Battery lid ass'y	44	3303182	Knob [for H, HC, E, E (BS)]
4	3348602	Pulley	24	3369849	Spring	45	3303092	Fine knob [for W, AU]
5	3340321	Spring	25	4436666	Terminal	46	3973051	Tuning knob [for W, AU]
6	3973081	Pulley holder	26	3369781	BAT spring	47	3348611	OG gear [for W, AU]
7	3973031	Pointer	27	2758012	Rod antenna	48	3303171	Select knob (×2)
8	4442031	Function lever	28	5895282	Rod antenna wire	49	4441859	Handle ass'y
9	3973061	Knob	29	4592528	3 ϕ × 8 flange head screw	50	4577817	3 ϕ × 30 Bind head screw (×8)
10	3950381	Damper ass'y (×2)	30	4578976	3 ϕ × 20 BT flange head screw (×2)	△ 51	2248925	Power trans. [for H, HC]
11	4591991	REC shaft	for CHASSIS ASSEMBLY			△	2248922	Power trans. [for E]
12	4441841	REC lever	31-1	2588501	TN-33 ZVC (TAPE 2)	△	2248923	Power trans. [for E (BS)]
13	3973093	Cassette lid	31-2	2588502	TN-33 ZVC (TAPE 1)	△	2248921	Power trans. [for W]
14	3973094	Cassette lid	32	3303163	Cassette button (×10)	△	2248924	Power trans. [for AU]
16	3973511	Speaker grille (×2)	33	3303164	Cassette button	△ 52	2706241	Power supply cord [for H, HC]
17	2402911	10 Speaker (×2)	34	3303165	Cassette button	△	2719449	Power supply cord [for E]
18	2403354	Piezo tweeter (×2)	35	4442082	REC arm ass'y	△	2717902	Power supply cord [for E, (BS)]
19	8691410	3 ϕ × 10 Bind head screw (×6)	36	4689531	Counter belt	△	2706264	Power supply cord [for W]
20	8699410	3 ϕ × 10 Bind head screw (×7)	37	2788864	Enplas counter	△	2706251	Power supply cord [for AU]
21	4578972	3 ϕ × 10 BT flange head screw (×9)		2789721	Leaf switch (×2)			
				2789711	Leaf switch			

TN-33 ZVC-681/682 (TAPE 2/TAPE 1)

ITEM No.	PART No.	DESCRIPTION	ITEM No.	PART No.	DESCRIPTION	ITEM No.	PART No.	DESCRIPTION
1	4815001	Chassis ass'y	35	4815014	Back tension spring	71	4815034	Pack spring
3	3959031	Record prevention lever (TAPE 2)	37	4815015	Motor bracket (TAPE 2)	75	4441801	Continuous play lever (TAPE 1)
4	4815002	REC spring	37	4451601	Motor bracket (TAPE 1)	76	4441831	Mecha. holder (TAPE 1)
6	4815003	Head panel	39	4690601	Belt	82	8691104	2 ϕ × 4 BT screw
7	3959051	Head base	40	4690591	Motor rubber (×3)	83	8691105	2 ϕ × 5 BT screw (×2)
8	4815004	Sensing plate ass'y	41	4586421	Special screw (×3)	84	8691108	2 ϕ × 8 Bind head screw
9	3365081	Spring for head	43	4816992	Motor ass'y	85	8691108	2 ϕ × 8 Bind head screw
10	4815005	Head panel spring	46	4815016	Eject lever ass'y	86	8691108	2 ϕ × 8 Bind head screw (×2)
12	4815006	Pinch roller ass'y	47	4815017	Eject lever spring	87	4578281	2.6 ϕ × 4 Screw
13	3365101	Spring						TAPE 2 (×4), TAPE 1 (×7)
14	3959061	Pressure roller arm stopper	50	4815021	Push button base (R)	88	8711305	2.6 ϕ × 5 Tapping screw
15	2555671	Record playback head	51	4815022	Push button base (L)	89	4578281	2.6 ϕ × 4 Screw
16	2555661	E.H. Head (TAPE 2)	52	4815023	Pause button lever ass'y	90	8691110	2 ϕ × 10 Bind tapping screw
16	4813851	Dummy head (TAPE 1)	53	4815024	Stop button lever	91	4701927	Washer
18	4815007	RF clutch arm ass'y	54	4815025	F.F. button lever	92	4701925	Washer (×2)
19	4815008	Take up roller arm ass'y	55	4815026	RWD button lever	93	4701926	Washer (×2)
20	4815009	Take up roller ass'y	56	4815027	Play button lever	95	4701921	Nylon washer
21	3365121	Spring (Take up roller arm)	57	4815028	REC button lever	96	4701924	Nylon washer
22	4586351	Collar (Take up roller arm)	58	3365171	Button lever spring (×3)	97	8691106	2 ϕ × 6 DT screw
24	3959111	F.F. gear	59	3365181	Spring (Button lever)	98	4586481	Collar screw
26	4815011	Flywheel ass'y	60	3365191	Button lever spring	99	4567419	3 ϕ × 5 DT screw (×2) (TAPE 1)
27	4815012	Flywheel holder	61	3365211	Spring (Button lever)			
28	3959151	Flywheel plate	62	4815031	Push button actuator ass'y			
29	3365131	Spring (Flywheel thrust)	63	3365201	Spring			
31	4815013	Take up reel ass'y	64	3959221	Actuator shaft			
32	4815014	Back tension spring (TAPE 1)	65	3959231	Actuator shaft			
32	3365151	Back tension spring (TAPE 2)	67	3959271	Pause lever			
34	3959381	Supply reel ass'y	68	4815032	Pause lever spring			
			69	4815033	Pause lever stopper			

REPLACEMENT PARTS LIST

CD : Ceramic discal
PP : Polypro-pylene

CC : Cylindrical ceramic
STY : Styrol

EL : Electrolytic
CF : Carbon film

MF : Mylar, film

H : U.S.A.

HC : Canada

E : Europe (except U.K.)

E (BS) : U.K.

AU : Australia

W : Asia & Latin American countries, etc.

SYMBOL No.	PART No.	DESCRIPTION					SYMBOL No.	PART No.	DESCRIPTION					SYMBOL No.	PART No.	DESCRIPTION				
CAPACITORS							C162	0208635	CD	5pF	±0.25%	50V	C471LR	0209734	CD	3300pF	±10%	50V		
C101	0208635	CD	5pF	±0.25%	50V								C472	0252331	EL	100μF		10V		
C102	0230008	CC	4.7pF	±10%	50V								C474	0209161	CD	1000pF	+80% -20%	50V		
C103	0209161	CD	1000pF	+80% -20%	50V	C175	0208680	CD	68pF	±5%	50V		C475LR	0274013	MF	2200pF	±10%	50V		
C104	0208664	CD	15pF	±5%	50V								C476	0275013	MF	0.022μF	±10%	50V		
C105	0208678	CD	56pF	±5%	50V	C176	0208686	CD	120pF	±5%	50V									
C106	0209721	CD	330pF	±10%	50V								C477	0244171	CD	0.01μF	+80% -20%	50V		
C107	0209161	CD	1000pF	+80% -20%	50V															
C108	0246426	CD	6pF	±0.5%	50V	C203	0209175	CD	0.047μF	+80% -20%	50V									
													C501LR	0252325	EL	47μF		10V		
C108	0246427	CD	7pF	±0.5%	50V	C205	0244171	CD	0.01μF	+80% -20%	50V		C502	0252531	EL	100μF		16V		
						C206	0249765	CD	0.047μF	±20%	50V		C503LR	0252325	EL	47μF		10V		
						C207	0244171	CD	0.01μF	+80% -20%	50V		C504LR	0276012	MF	0.15μF	±10%	50V		
C109	0248480	CD	10pF	±5%	50V	C208	0252233	EL	330μF		6.3V		C505LR	0252235	EL	470μF		6.3V		
						C209	0209161	CD	1000pF	+80% -20%	50V		C506	0252541	EL	1000μF		16V		
C109	0246413	CD	3pF	±0.25%	50V	C210	0244173	CD	0.022μF	+80% -20%	50V		C507	0252532	EL	220μF		16V		
						C211	0252813	EL	3.3μF		50V		C508	0252532	EL	220μF		16V		
C111	0244171	CD	0.01μF	+80% -20%	50V	C212	0252322	EL	22μF		10V		C509LR	0244161	CD	1000pF	+80% -20%	50V		
C112	0246415	CD	5pF	±0.25%	50V								C510	0256676	EL	47μF		10V		
C113	0209161	CD	1000pF	+80% -20%	50V															
						C214	0209175	CD	0.047μF	+80% -20%	50V		C601	0244171	CD	0.01μF	+80% -20%	50V		
C121	0208684	CD	100pF	±5%	50V	C215	0252805	EL	0.47μF		50V									
						C216	0244173	CD	0.022μF	+80% -20%	50V		C604	0244171	CD	0.01μF	+80% -20%	50V		
C122	0208684	CD	100pF	±5%	50V	C217	0208684	CD	100pF	±5%	50V									
C123	0209161	CD	1000pF	+80% -20%	50V	C219	0244173	CD	0.022μF	+80% -20%	50V		RESISTORS							
												R101	0113615	CF	1kΩ	±5%	SRD1/6P			
C151	0244171	CD	0.01μF	+80% -20%	50V	C301	0252813	EL	3.3μF		50V	R102	0113579	CF	33Ω	±5%	SRD1/6P			
						C302	0209175	CD	0.047μF	+80% -20%	50V	R103	0113679	CF	470kΩ	±5%	SRD1/6P			
C152	0244171	CD	0.01μF	+80% -20%	50V	C303	0268444	PP	470pF	±5%	100V	R104	0113583	CF	47Ω	±5%	SRD1/6P			
						C304	0252803	EL	0.33μF		50V	R105	0113615	CF	1kΩ	±5%	SRD1/6P			
C152	0208632	CD	2pF	±0.25%	50V	C305	0252811	EL	1μF		50V	R106	0113679	CF	470kΩ	±5%	SRD1/6P			
						C306LR	0209735	CD	4700pF	±10%	50V	R107	0113615	CF	1kΩ	±5%	SRD1/6P			
C153	0230014	CD	12pF	±5%	50V	C307LR	0209765	CD	0.047μF	±20%	50V									
						C308LR	0252805	EL	0.47μF		50V	R107	0113617	CF	1.2kΩ	±5%	SRD1/6P			
C154	0230008	CD	4.7pF	±10%	50V	C309	0209161	CD	1000pF	+80% -20%	50V									
												R107	0113619	CF	1.5kΩ	±5%	SRD1/6P			
C154	0230006	CD	3.3pF	±10%	50V	C401	0252805	EL	0.47μF		50V									
						C402LR	0244171	CD	0.01μF	+80% -20%	50V	R108	0113639	CF	10kΩ	±5%	SRD1/6P			
C155	0208650	CD	10pF	±0.5%	50V	C403LR	0252802	EL	0.22μF		50V	R109	0113663	CF	100kΩ	±5%	SRD1/6P			
						C404LR	0209163	CD	2200pF	+80% -20%	50V									
C155	0208647	CD	7pF	±0.5%	50V	C405LR	0252803	EL	0.33μF		50V	R151	0113591	CF	100Ω	±5%	SRD1/6P			
						C406LR	0252803	EL	0.33μF		50V									
C156	0208662	CD	12pF	±5%	50V	C407LR	0252803	EL	0.33μF		50V	R152	0113675	CF	330kΩ	±5%	SRD1/6P			
						C407LR	0252803	EL	0.33μF		50V									
C156	0208650	CD	10pF	±0.5%	50V	C408L	0249765	CD	0.047μF	±20%	50V	R153	0113645	CF	18kΩ	±5%	SRD1/6P			
						C408R	0209765	CD	0.047μF	±20%	50V									
C157	0208650	CD	10pF	±0.5%	50V							R153	0113643	CF	15kΩ	±5%	SRD1/6P			
C157	0208635	CD	5pF	±0.25%	50V	C421LR	0252802	EL	0.22μF		50V									
						C422LR	0252803	EL	0.33μF		50V	R154	0113609	CF	560Ω	±5%	SRD1/6P			
C158	0275011	MF	0.01μF	±10%	50V	C423LR	0209163	CD	2200pF	+80% -20%	50V									
						C424LR	0252803	EL	0.33μF		50V	R156	0113645	CF	18kΩ	±5%	SRD1/6P			
C158	0275012	MF	0.015μF	±10%	50V	C425LR	0252803	EL	0.33μF		50V									
C159	0268321	PP	360pF	±5%	100V	C441	0252232	EL	220μF		6.3V	R201	0113583	CF	47Ω	±5%	SRD1/6P			
						C442LR	0252521	EL	10μF		16V	R204	0113643	CF	15kΩ	±5%	SRD1/6P			
C159	0268442	PP	1500pF	±5%	100V	C443LR	0209161	CD	1000pF	+80% -20%	50V	R206	0113597	CF	180Ω	±5%	SRD1/6P			
						C444	0252333	EL	33μF		10V	R207	0129543	CF	33Ω	±5%	SRD1/4P			
C160	0221317	STY	180pF	±5%	50V	C445LR	0252325	EL	47μF		10V	R208	0113663	CF	100kΩ	±5%	SRD1/6P			
						C446LR	0252323	EL	33μF		10V									
C160	0268321	PP	360pF	±5%	100V	C449	0252331	EL	100μF		10V	R304	0113645	CF	18kΩ	±5%	SRD1/6P			
						C450	0252232	EL	220μF		6.3V	R305	0113603	CF	330Ω	±5%	SRD1/6P			
C161	0208648	CD	8pF	±0.5%	50V	C451LR	0209764	CD	0.033μF	±20%	50V	R306	0113615	CF	1kΩ	±5%	SRD1/6P			
						C453LR	0252804	EL	0.15μF		50V	R307LR	0113639	CF	10kΩ	±5%	SRD1/6P			
C161	0208666	CD	18pF	±5%	50V	C454	0252335	EL	470μF		10V	R308LR	0113655	CF	47kΩ	±5%	SRD1/6P			

SYMBOL No.		PART No.		DESCRIPTION		SYMBOL No.		PART No.		DESCRIPTION		SYMBOL No.		PART No.		DESCRIPTION																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																		
												MISCELLANEOUS																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																						
R309LR	0113615	CF	1kΩ ±5%	SRD1/6P	Q401LR	2319091	HIT9014N (C)	CF201	2135321	Ceramic filter 10.7	CV101	0282193	Variable capacitor [for H, HC]	CV101	0282182	Variable capacitor [except H, HC]	CV102	0282193	Variable capacitor [for H, HC]	CV102	0282182	Variable capacitor [except H, HC]	CV151	0282193	Variable capacitor [for H, HC]	CV151	0282182	Variable capacitor [except H, HC]	CV152	0282193	Variable capacitor [for H, HC]	CV152	0282182	Variable capacitor [except H, HC]	CT101	0282193	Variable capacitor [for H, HC]	CT101	0282182	Variable capacitor [except H, HC]	CT102	0282193	Variable capacitor [for H, HC]	CT102	0282182	Variable capacitor [except H, HC]	CT151	0282193	Variable capacitor [for H, HC]	CT152	0282193	Variable capacitor [for H, HC]	CT151	0283130	Semi variable capacitor [except H, HC]	CT151	0283130	Semi variable capacitor [except H, HC]	RT301	0199331	Semi variable resistor FM MPX adj.	LED1	2397753	LN217RP	LED2	2397753	LN217RP	LED3	2397753	LN217RP	S001	2789721	Leaf switch (POWER SW.)	S002	2789721	Leaf switch (POWER SW.)	S003	2789711	Leaf switch (CONTINUOUS SW.)	S201	2629282	Slide switch (BAND SW.) [except H, HC]	S201	2629271	Slide switch (BAND SW.) [for H, HC]	S401	2629291	Slide switch (REC/P.B. SW.)	S402	2628341	Slide switch (INN MIC, SP SW.)	S403	2628342	Slide switch (FM ST-MONO, RIF A-B SW.) [except H, HC]	S501	2629301	Slide switch (FUNCTION SW.)	S601	2629261	Slide switch (AC BATTERY)	△ S602	2618471	VOL switch (VOLTAGE SELECTOR) [for W]	△ F601	2728073	Fuse T1.25A [except H, HC]	△ F601	2728062	UL Fuse 1.25A [for H, HC]	△	2727832	Fuse holder	J401LR	2678151	Pin Jack	J402LR	2679371	3.5 Jack	J601	2678282	DC Jack [for W]	J501	2678234	Headphone Jack	2737441	Mic																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																				
R310	0113631	CF	4.7kΩ ±5%	SRD1/6P	Q402LR	2319091	HIT9014N (C)																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																											



HITACHI SALES EUROPA GmbH

Postfach 801060 Rungedamm 2, 2050 Hamburg 80,
West Germany
Tel. 040-734 11-0

HITACHI SALES (U.K.) Ltd.

Hitachi House, Station Road, Hayes, Middlesex UB3
4DR, England
Tel. 01-848-8787

HITACHI SALES SCANDINAVIA AB

Rissneleden 8, Box 7138, 172-07 Sundbyberg, Sweden
Tel. 08-98 52 80

HITACHI SALES NORWAY A/S

Oerebeek 1620, Gressvik, P.O. Box 46, N-1601,
Fredrikstad, Norway
Tel. 032-28255

SUOMEN HITACHI OY

Takojankatsu 5, 15800 Lahti 80, Finland
Tel. Lahti 44 241

HITACHI SALES A/S

Kuldysen 13, DK-2630, Taastrup, Denmark
Tel. 02-999200

HITACHI SALES A.G.

Bahnhofstrasse, 19, 5600 Lenzburg, Switzerland
Tel. 064-513621

HITACHI SALES WARENHANDELS GMBH

A-1180/Wien, Kreuzgasse 27, Austria
Tel. 0222-439367

HITACHI SALES ITALIANA, S.P.A.

Via Cristoforo Colombo 49, Trezzano sul naviglio
(Milano), Italy
Tel. 02-44 59 031

HITACHI SALES BELGIUM S.A.

56 Chaussee de Namur B-1400 Nivelles, Belgium
Tel. (003267) 227181

HITACHI SALES IBERICA, S.A.

Gran Via Carlos Tercero, 101, 1-1, Barcelona-28,
Spain
Tel. 330-8652

HITACHI MAROC (RADIO TV ELECTRO-MANAGER), S.A.

Rue du Havre, Casablanca, Morocco
Tel. 30-73-68, 30-73-57

HITACHI CANARIAS S.A.

Calle San Francisco No. 19, Santa Cruz de Tenerife
Canary Islands
Tel. 24-64-98

HITACHI SALES (HELLAS) LTD.

110 Syngrou St., Athens, Greece
Tel. 9219082, 9233469

HITACHI SALES (MALAYSIA) SDN. BHD.

17, Jalan 20/16, Petaling Jaya, Selangor, Malaysia
Tel. 762523, 769918, 769836, 762594

HITACHI (SINGAPORE) PTE., LTD.

18, Pasir Panjang Road = 01-03 PSA Multi-Storey
Complex Singapore 0551
Tel. 2738102

HITACHI SALES (THAILAND) LTD.

2242-48, New Petchburi Road, Bangkok, Hueykuang
Bangkok, Thailand
Tel. 314-2741

HITACHI ELECTRIC SERVICE CO., (HONG KONG) LTD.

4th Floor Leun Tai Industrial Bldg., 72-76 Kwai Cheong
Road Kwai Chung N.T., Hong Kong
Tel. 240126

HITACHI SALES AUSTRALIA PTY LTD.

153 Keys Road, Moorabbin, Victoria 3189 Australia
Tel. 555-8722

**HITACHI SALES CORPORATION OF AMERICA
Eastern Regional Office**

1290 Wall Street West, Lyndhurst, New Jersey 07071, U.S.A.
Tel. 201-935-8980

Mid-Western Regional Office

1400 Morse Ave., Elk Grove Village, Ill. 60007, U.S.A.
Tel. 312-593-1550

Southern Regional Office

510 Plaza Drive, College Park, Georgia 30349, U.S.A.
Tel. 404-763-0360

Western Regional Office

401 West Artesia Boulevard, Compton, California 90220 U.S.A.
Tel. 213-537-8383

HITACHI SALES CORPORATION OF HAWAII, INC.

3219 Koapaka Street, Honolulu, Hawaii 96819, U.S.A.
Tel. 808-836-3621

HITACHI (HSC) CANADA INC.

3300 Trans-Canada Highway, Pointe Claire, Quebec,
H9R 1B1, Canada
Tel. 514-697-9150

Hitachi Sales Centroamericans, S.A.

San Rafael de Excazu, (Apartado 10272), San Jose,
Costa Rica
Tel. 28-20-11, 28-00-37

Hitachi Sales Corporation de Panama, S.A.

Nuevo Repato E1 Camen, Calle Ramon Arias y Calle B
Edificio Brasil 100. (Apartado 7657) Panama 5
Panama City, Rep. of Panama
Tel. 61-3100, 61-4305

Hitachi Sales de Chile Cia., Ltda.

Av. Mexico, 0183, Casilla 9793, Correo Central
Santiago, Chile
Tel. 774165

HITACHI-FRANCE S.A.

95-101 Rue Charles Michels,
93200 SAINT-DENIS,
France
Tel. 821 6015

HITACHI LTD. TOKYO JAPAN

Head Office: THE HITACHI ATAGO BLDG.
No. 15-12, 2-Chome Nishi-Shinbashi
Minato-Ku, Tokyo 105, Japan
Tel. Tokyo (03) 502-2111